GEN 2.4 LOCATION INDICATORS

The location indicators marked with an asterisk (*) cannot be used in the address component of AFS messages.

Table 1:International Airports

ENCODE		DECODE	
Location	Indicator	Indicator	Location
BANJA LUKA	LQBK	LQBK	BANJA LUKA
MOSTAR	LQMO	LQMO	MOSTAR
SARAJEVO	LQSA	LQSA	SARAJEVO
TUZLA	LQTZ	LQTZ	TUZLA

Table 2:Airfields

ENCODE		DECODE	
Location	Indicator	Indicator	Location
BIHAĆ	LQBI*	LQBI*	BIHAĆ
BOSANSKI PETROVAC	LQMP*	LQBZ*	ZALUŽANI - BANJA LUKA
CILJUGE - ŽIVINICE	LQCG*	LQCG*	CILJUGE - ŽIVINICE
GORICE - BRČKO	LQGO*	LQGO*	GORICE - BRČKO
JEGIN LUG - TUZLA	LQJL*	LQJL*	JEGIN LUG - TUZLA
KREŠEVO	LQKR*	LQKR*	KREŠEVO
LIVNO	LQLV*	LQLH*	TARČIN
NIŠIĆI	LQNI*	LQLV*	LIVNO
POPOVI - BIJELJINA	LQPP*	LQMP*	BOSANSKI PETROVAC
PRIJEDOR	LQPD*	LQNI*	NIŠIĆI
TARČIN	LQLH*	LQPD*	PRIJEDOR
VISOKO	LQVI*	LQPP*	POPOVI - BIJELJINA
ZALUŽANI - BANJA LUKA	LQBZ*	LQVI*	VISOKO

Table 3:Administrative Locations

ENCODE		DECODE	
Location	Indicator	Indicator	Location
BHDCA	LQBH	LQBH	BHDCA

Table 4:Operational Locations

ENCODE		DECODE	
Location	Indicator	Indicator	Location
SARAJEVO FIR	LQSB*	LQSB*	SARAJEVO FIR
AFTN COM Center Sarajevo	LQQQ	LQQQ	AFTN COM Center Sarajevo

THIS PAGE INTENTIONALLY LEFT BLANK